



## Know Your Chromebook

---

### 什么是Chromebook?

Chromebook 是一种使用谷歌Chrome计算机操作系统的平板电脑。（取代微软的Window 或者苹果的Mac操作系统）这种设计主要就是为了上网时可以更方便使用所有的谷歌软件。

### 第一， 设置你的Chromebook


1. 取出你的Chromebook, 按下电源开关-开机。
2. 你会看到欢迎屏幕。
3. 点击 Chinese 框格， 选择你的语言。
4. 你可以点击下拉菜单选择你想用的语言
5. 然后点击 OK 确定。

### Choose your language & keyboard

---


Language		English (United States) ▼
Keyboard		US ▼

---



可选项：想要打开 Chromebook 的辅助功能，选择 Accessibility

Welcome!



选好你想要用的方式，然后单击 OK 确定。

## Accessibility Settings

You can customize this device to fit your needs. These accessibility features can be changed later in Settings.

ChromeVox (spoken feedback)  
Off



Large mouse cursor  
Normal



High contrast mode  
Off




Screen magnifier  
Off



Select to speak  
Off



Click the buttons to turn any of these options on.



English (United States)

Accessibility



然后单击 Let's go

选择你的互联网，输入你的密码，然后单击 Next 继续。

## Connect to network

To restore your data, you need an internet connection

 HOME

 GUEST

[< Back](#)



阅读谷歌的操作系统使用协议，然后单击 Accept and continue 继续。

# Google Chrome OS terms

**Google Chrome OS Terms**

BY USING THIS DEVICE, YOU AGREE TO BE BOUND BY THE FOLLOWING TERMS.


The Chrome OS device provided to you includes Chrome OS software such as the operating system executable code, embedded software, firmware, fonts, and other data, including any updates (referred to collectively as the "Software"). These Terms apply to the Software and your use of the Software with your Chrome OS device. Most source code for Google Chrome is available free of charge under an open-source software license agreement at <http://www.chromium.org>.

**1. Your relationship with Google**

## System security setting

Optional: Help make Chrome OS better by automatically sending diagnostic and usage data to Google. [Learn more](#)

[← Back](#)



输入你的邮箱地址， 点击 Next 继续。




## Sign in to your Chromebook

Email or phone

[Forgot email?](#)

[More options](#)



输入你的邮箱密码， 点击 Next



# Welcome

 drewbrunsman@gmail.com

Email or phone

..... 







[Forgot password?](#)




同步你的Chrome 设置， 点击 Accept and continue.


 **Chrome sync**  
Your bookmarks, history, passwords, and other settings will be synced to your Google Account so you can use them on all your devices.

 **Personalize Google services**  
Google may use your browsing history to personalize Search, ads, and other Google services. You can change this anytime at [myaccount.google.com/activitycontrols/search](https://myaccount.google.com/activitycontrols/search)

Review sync options following setup




你的平板电脑已经设置好并且用你的邮箱地址上网。你的书签，辅助功能，以及和你谷歌账户相连的软件将自动显示。





**下一步，让我们看看一些设置。**

设置版面是隐藏的。点击屏幕右下角的时间处，设置版面会弹出。




在弹出的设置版面上你可以快速调整你的设置。点击图标去关闭或者打开。




想要在平板电脑上改变更多的设置和选择可以点击设置图标。让我们改变一下电脑的背景设置。 点击设置图标。



在屏幕左边你可以看到一个设置目录。要改变屏幕背景， 点击 Appearance




然后点击 Wallpaper 壁纸




查看各个类型中的图片




点击一张你想要作背景的图片，你的电脑屏幕会立刻发生变化。你可以反复试验。




现在点击背景选择窗口的右上角的X 关闭这个窗口。 注意：任何窗口右上角的X都有相同的作用。




我们又回到设置目录，这里我们可以进行其他选择和改变。点击不同的分类可以看到在这一分类中我们可以选择和改变什么。提醒：完成后别忘了点击X 关闭这个窗口。



现在让我们看一下我们都有什么软件。点击屏幕左下角的启动钮。



点击启动钮后，屏幕会出现一个搜索栏框。你可以在那里寻找你电脑和网上的任何东西。同时出现几个你最常用的软件。如果想查看你所有的软件，点击向上的箭头。



现在你可以看见更多的软件。点击右边的白的，可以看下一页的软件。




查看你的文件，点击文件袋图标。






点击我的文件看自己的存档文件。点击Google Drive 看存在那里的文件。右栏文件需双击才能打开。




记住关闭你的账户如果别人需要使用你的平板电脑。那样别人就不能看到你的文件和邮件。



当你关闭你的账户之后，你会回到电脑主界面。其他人就可以以访问者身份从这里开始使用这个电脑但不能查看你的文档。



如果你和其他人合用你的电脑，你可以点击 Add Person。他们需要使用他们自己的邮箱地址来加入。一台电脑可以允许多人加入。每个人都只能查看自己的文件和邮件。



如果你有更多问题，你可以访问以下网址：

[Google's Chromebook Simulator by clicking on this link](#) 或输入

<https://partnerdash.google.com/apps/simulator/chromebook> 在你的搜索栏。

**祝贺你成功的设置你的新电脑！**